



| | | | | | | | |
|---|---|-----|---------|---|--|-----|---------|
| A | Front brake disc screw | M5 | 8~10Nm | N | Rear brake disc screw | M6 | 10~12Nm |
| B | Drop out pinch bolts | M5 | 6Nm | O | Front& Rear brake caliper bracket screw | M6 | 12Nm |
| C | Front wheel axle nut | M12 | 20~25Nm | P | Rear sprocket screw | M8 | 33Nm |
| D | triple clamp screw | M6 | 8Nm | Q | Rear wheel axle screw | M12 | 55~60Nm |
| E | Direct mount screw | M6 | 8-10Nm | R | Front sprocket screw | M6 | 18Nm |
| F | Controller upper mount screw | M6 | 8-10Nm | S | Swing arms axle screw | M10 | 45~50Nm |
| G | Controller lower/right & left mount screw | M6 | 8Nm | T | Motor mount screw | M8 | 40~45Nm |
| H | subframe screw | M8 | 15~20Nm | U | Rear shock lower screw | M8 | 25~30Nm |
| I | Motor pulley nut | M12 | 40~50Nm | V | Battery botom bracket screw | M6 | 8Nm |
| J | Belt pulley screw | M6 | 10~12Nm | W | Front battery protection Plate screw | M6 | 8Nm |
| K | Rear shock, Shock linkage, Rear shock absorber connecting rod screw | M8 | 20~25Nm | X | Battery cover screw | M6 | 8Nm |
| L | Foot pegs mount bracket screw | M8 | 25~30Nm | Y | Ignition key cover plate &Key lock cover screw | M6 | 5Nm |
| M | Footpeg mount screw | M10 | 40~45Nm | | | | |

